


Welcome to your nook™



- **Power Button**

Press once and release to turn your nook on or to put it to sleep. Press and hold for about 7 seconds to completely power off your nook.

- **Reading Screen**

This is where you read your eBooks, newspapers, magazines, PDF documents and more. You can also shop Barnes & Noble's eBookstore for great new titles.

- **Page Turn Buttons**

Turn forward one page or back one page.



- **Home Button**

Press any time to go to your nook's Home screen and see *the daily*, *my library*, *shop*, *reading now* and *settings*.

- **Color Touchscreen**

The lower segment of your nook is a Color Touchscreen.

Use your fingers to turn pages, enter text, navigate through *the daily* and *my library*, shop B&N's eBookstore, review what you are *reading now* or change your preferences in the *settings* area.




USB Cable



Power Adapter

Both items above are included in the package along with your new nook.



Color Touchscreen Home

The Home screen is your jumping off point to the different areas of your nook. From here you can select:


- the daily*—newspapers, lending notifications, and more
- my library*—all of your eBooks, PDFs, and other downloads
- shop*—Barnes & Noble's eBookstore
- reading now*—shortcut to what you're currently enjoying
- settings*—preferences and user settings



Color Touchscreen Actions

Use these icons on the Color Touchscreen to:

- ↕ Move the cursor up and down on the Reading Screen
- Select an item on the Reading Screen
- ▮ Swipe up and down on the Color Touchscreen to scroll through menus



Keyboard

The on-screen keyboard automatically appears when any text input is needed. Use it to search for titles in the eBookstore or take notes as you read.

- Touch the Shift key ↕ to capitalize letters
- Touch the 123 key to see the primary number and punctuation keyboard
- Touch the #+= key when using the number keyboard to see secondary characters and punctuation marks



View by Cover

Viewing your eBooks is as easy as moving your finger. Swipe across their covers to find the one you want.

Let's get started

This Quick Start Guide gives you the basics to use your nook.™
Please read the User Guide for complete information on all the features of your nook. It comes pre-loaded on your nook in the My Documents section of *my library*. To see the complete User Guide, press *my library* on your nook's Color Touchscreen. A PDF version can also be accessed at www.nook.com/support.


nook™

I. Charge your nook

You must fully charge your nook before using it the first time.

- a) Press the power button on the top of your nook to turn it on.
- b) Plug your nook into a wall outlet.

You can use your nook while it charges. The yellow, charging indicator light illuminates while charging. When the light turns off, your nook is fully charged. Typical charging time is approximately 3½ hours by AC.



You can also charge your nook by connecting it to a USB port on your computer. Please refer to your User Guide for additional instructions about this feature.

If you experience any problems, please contact Customer Service:


www.nook.com/support

Toll-free in the United States: 1-800-THE-BOOK (843-2665)

2. Register your nook

You need to register your nook to a Barnes & Noble online account to buy and enjoy eBooks and periodicals. If you have an account, enter the e-mail address and password used to access your Barnes & Noble online account.

If you don't have a bn.com account, go to www.nook.com/setup to create an account on-line. Please have a credit card ready to complete this process. Once created, you will still need to register your nook to this account. Press *settings* and then select *device* on your nook's Color Touchscreen to register.




3. Check the daily

Make *the daily* your first read on your nook each day. We'll be adding many great Barnes & Noble exclusives in the weeks and months ahead.

Get the news and latest articles from your subscriptions.

See invitations from friends to read eBooks they've lent to you.




4. Visit the B&N eBookstore

After your nook is registered, press the Home button and then select *shop* on the Color Touchscreen to explore the world of eBooks.

You can browse, sample for free and then buy eBooks.

Get today's paper or subscribe to newspapers and magazines.

To purchase an eBook on your nook, find the title, press "Buy," and follow the on-screen prompts. The item will be charged to your account's credit card and automatically download to your nook.




5. Read an eBook

When you buy an eBook, it immediately downloads to your nook. Just press *read* on the Color Touchscreen to open it.

Swipe the Color Touchscreen to turn pages—just like flipping pages in an actual book. If you prefer, use the previous/next page turn buttons on the side of your nook.

From the Home screen, touch *my library* to see your eBooks, newspapers and magazines already saved on your nook.

Go to www.nook.com for tutorials and tips on how to make reading more enjoyable than ever before!



Meet your nook™

- Get the latest bestsellers, newspapers and magazines instantly with free wireless.
- Highlight, bookmark and take notes as you read.
- LendMe™ technology lets you loan your eBooks to friends.
- Customize your nook's screensaver with favorite photos.
- Press *my library* on your nook's Color Touchscreen to see the User Guide that explains all of these great features.

A unique in-store experience

Visit your local Barnes & Noble store for exclusive content and special offers:

- Get articles, sneak previews and unique selections from famous authors.
- Receive coupons and discounts.
- Browse and read any available eBook for free.*



Barnes & Noble, Inc. 122 Fifth Avenue, New York, NY 10011 USA.

© 2009 Barnes & Noble, Inc. All rights reserved. nook and the nook logo are trademarks of Barnes & Noble, Inc. or its affiliates. Patent Pending. Screenshots and product images are simulated and for instructional purposes only. They may differ from the actual product and are subject to change without notice. Your use of the nook is subject to the nook Terms of Service located here: www.nook.com/legal. Contains Reader® Mobile technology by Adobe Systems Incorporated.

*Coming in 2010.